Mobility Sound
全笙科技有限公司

# BH-P05

Bluetooth Speaker Microphone Adapter for Radio User Manual

## 1. Introduction of the product




## 2. Pairing with your Bluetooth Speaker Microphone Adapter

1. Press the PTT button down and hold it.
2. Switch the power from OFF to ON.
3. Waiting for the LED shows blue and red light flashing alternately.
4. Release PTT and it is coming to pair mode.

## 3.Pairing with your Bluetooth Radio Dongle

1. Plug the dongle to your radio.
2. Press the PTT button down and hold it and turn on the radio.
3. Waiting for 3 seconds the LED will begin twice flash per second. Then release PTT, It means coming to pair mode.

## 4. Using

1. After pairing the Bluetooth Speaker Microphone and Bluetooth Radio Dongle , Both of the LED blue light will be 4 flashes/sec. It stands for successful pairing.
2. You can hear and press PTT on the Bluetooth Speaker Microphone Adapter, and then can talk with another radio in same channel (please take the Bluetooth microphone near your mouth).

## 5. Charge

1. When LED red light on, it means the Bluetooth speaker microphone adapter ‘s battery is low voltage.
2. Please connect the charge cable into the charge hole for charging, then the LED light will still red on.
3. While the Bluetooth speaker microphone adapter is charging, you can use it.
4. When charging is finish, the LED light will transfer to green light.

MobilitySound Technology LTD.
www.mobilitysound.com
info@mobilitysound.com